

# **54" GIANT SIZE ROLL SUPER REFLECTIVE METALLIZED 1ml FILM**

## **Instructions:**

For best results, use a staple gun, razor knife and duct tape.

1. Remove all sharp objects off your wall or freestanding panels
2. Measure wall, cut film with razor blade to length.
3. Reinforce corners by taping over where staples are to go.
4. Start at top and work down. Hold film, then staple over tape.

**USE IMMEDIATELY!**

**DO NOT STORE THIS ROLL NEAR DAMPNES.**

Distributed by HYDROFARM INC. • PETALUMA, CA