

Active Air Flanges

AC4F, AC5F, AC6F, AC8F, AC10F, AC12F, AC6FW, AC8FW

Parts:

- Flange.....x 1 ea.
- Sealing Foam.....x 1ea.
- Screws for secure fit.....x 6ea.

Installation: Active Air Carbon Filters

1. Remove the film from the sealing foam to expose the adhesive side
2. Apply the foam seal to the outer edges of the flange on the reverse side of the outflow
3. Place the flange foam side down onto the opening surface of the carbon filter and center the position to ensure uniform placement
4. Using the self-tapping screws included in the parts kit, secure the flange to the mouth of the filter through the designated pilot holes pre-fabricated on the flange
5. Ensure the fit is secure and connect via aluminum duct to the appropriate inline fan (Hydrofarm offers standard ducting [ACDC codes] in sizes that fit each flange).

Air flow recommendation is to pull through the filter and not blow into it.